

FIG. 1

FIG. 2




FIG. 2




FIG. 3

120      142      144

SEARCH ALL MY QUOTES      REQUEST NEW QUOTE

---

136      138      140

PRODUCT CONFIGURATOR      PREVIEW QUOTE      SAVE QUOTE      SUBMIT ORDER

USER NAME: JOHN DOE      CUSTOMER NAME:

2/21/2001      QUOTE NUMBER:

---

124      126      128      130      132      134      122

CUSTOMER      PROJECT DETAILS      SYSTEM      ENGINE GENERATOR      DISTRIBUTION BREAKER      PRICING      122

1      2      3      4      5      6      122

CUSTOMER LOOKUP      ☐ REQUIRED FOR ORDER

146

148 CUSTOMER NAME

160

152 CUSTOMER NUMBER

152 BILLING INFORMATION 150

152 ADDRESS LINE 1

152 ADDRESS LINE 2

154 CITY

156 STATE

158 ZIP

162

---

136      138      140

PREVIEW QUOTE      SAVE QUOTE      SUBMIT ORDER

FIG. 4

170      142      144

SEARCH ALL MY QUOTES      REQUEST NEW QUOTE

136      138      140

PRODUCT CONFIGURATOR      PREVIEW QUOTE      SAVE QUOTE      SUBMIT ORDER

USER NAME: JOHN DOE      CUSTOMER NAME:

2/21/2001      QUOTE NUMBER:

124      126      128      130      132      134      122

CUSTOMER      PROJECT DETAILS      SYSTEM      ENGINE GENERATOR      DISTRIBUTION BREAKER      PRICING

1      2      3      4      5      6

PROJECT DETAILS      172      ☐ REQUIRED FOR ORDER

180      SHIPPING INFORMATION      174

PROJECT NAME      ADDRESS LINE 1

182      LOCATION      ADDRESS LINE 2

184      CONTACT NAME      192      194      CITY

186      CONTACT EMAIL      196      STATE

188      CONTACT PHONE      198      ZIP

190      CONTACT FAX

178

ENGINEERING FIRM      176      216      ELECTRICAL CONTRACTOR

200      FIRM NAME      COMPANY NAME

ENGINEER NAME      218      CONTRACTOR NAME

202      CITY      STATE      206      CONTRACTOR

204      COUNTRY      220      E-MAIL

208      ENGINEER      CONTRACTOR PHONE

210      E-MAIL      222      CONTRACTOR

ENGINEER      224      FAX

212      PHONE

ENGINEER      214      FAX

226

136      138      140

PREVIEW QUOTE      SAVE QUOTE      SUBMIT ORDER

FIG. 5

230
142
144

SEARCH ALL MY QUOTES
REQUEST NEW QUOTE

PRODUCT CONFIGURATOR  
USER NAME: JOHN DOE  
2/21/2001

136 PREVIEW QUOTE    138 SAVE QUOTE    140 SUBMIT ORDER

CUSTOMER NAME:  
QUOTE NUMBER:

124 CUSTOMER

1 2 3 4 5 6

126 PROJECT DETAILS

128 SYSTEM

130 ENGINE GENERATOR

DISTRIBUTION BREAKER

132 PRICING

134 122

SYSTEM ☐ REQUIRED FOR ORDER

232 — SYSTEM VOLTAGE SELECT ONE ▾

234 — NUMBER OF GENERATORS SELECT ONE ▾

236 — SIZE OF GENERATORS SELECT ONE ▾

238 — ENCLOSURE SELECT ONE ▾

240 — UL LISTED SELECT ONE ▾

242 — SHORT CIRCUIT RATIO SELECT ONE ▾

244 — MAIN BUS SIZE SELECT ONE ▾

246 — MAIN BUS METERING SELECT ONE ▾

▶ CONTINUE 248

136 PREVIEW QUOTE    138 SAVE QUOTE    140 SUBMIT ORDER

FIG. 6

250      142      144

SEARCH ALL MY QUOTES      REQUEST NEW QUOTE

---

PRODUCT CONFIGURATOR  
USER NAME: JOHN DOE  
2/21/2001

136      138      140

PREVIEW QUOTE    SAVE QUOTE    SUBMIT ORDER

CUSTOMER NAME:  
QUOTE NUMBER:

---

124  
CUSTOMER

126  
PROJECT  
DETAILS

128  
SYSTEM

130  
ENGINE  
GENERATOR

132  
DISTRIBUTION  
BREAKER

134    122  
PRICING

1	2	3	4	5	6	
---	---	---	---	---	---	--

ENGINE-GENERATOR ☐ REQUIRED FOR ORDER

252 MAKE OF GENERATOR  ▼

254 GOVERNOR/LOAD SHARING MODULE  ▼

VOLTAGE REGULATION  ▼

256 ALARM SHUTDOWN  ▼

258 GROUNDING SYSTEM  ▼

260

262 PT CONFIGURATION  ▼

264 BREAKER TRIP UNIT TYPE  ▼

266 BREAKER TRIP UNIT MODEL  ▼

BREAKER SIZE  ▼

268

270

MX BOOO LED ANNUNCIATOR  ▼

272 SPARE INPUT NO.1  ▼

SPARE INPUT NO.2  ▼

SPARE INPUT NO.3  ▼

SPARE INPUT NO.4  ▼

EVENT MESSAGE

EVENT MESSAGE

EVENT MESSAGE

EVENT MESSAGE

274

▶ CONTINUE 276

---

136      138      140

PREVIEW QUOTE    SAVE QUOTE    SUBMIT ORDER

0977057-051401

FIG. 7

280      142      144

SEARCH ALL MY QUOTES      REQUEST NEW QUOTE

136      138      140

PRODUCT CONFIGURATOR      PREVIEW QUOTE      SAVE QUOTE      SUBMIT ORDER

USER NAME: JOHN DOE      CUSTOMER NAME:

2/21/2001      QUOTE NUMBER:

124      126      128      130      132      134      122

CUSTOMER      PROJECT DETAILS      SYSTEM      ENGINE GENERATOR      DISTRIBUTION BREAKER      PRICING

1	2	3	4	5	6	
---	---	---	---	---	---	--

DISTRIBUTION BREAKER      ☐ REQUIRED FOR ORDER

282      TRIP UNIT TYPE  ▼

TRIP UNIT MODEL  ▼

284

1	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
2	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
3	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
4	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
5	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
6	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
7	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
8	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
9	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
10	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
11	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼
12	SELECT FRAME SIZE ▼	SELECT ATS ▼	SELECT LOAD BLOCK PRIORITY ▼

286      288      290       292

136      138      140

PREVIEW QUOTE      SAVE QUOTE      SUBMIT ORDER

FIG. 8